



Shoreline Program Management Map Tool


1. Once you are on the city's [mapping page](#), click on the Shoreline Management Program Map.




2. Once you've read the terms and conditions, click the box to agree, click OK



3. In the upper left-hand corner of the screen, you will see a search bar. Here, you will enter either an address or parcel number.




4. Once you start to type, the search will look for possible matches. Click on the address or parcel you wish to see.



5. On the right-hand side, you will see a Layer List. The Shoreline Designation layer should already be selected. This layer approximates the 200' shoreline jurisdiction but is not a precise boundary. Site-specific bio-physical characteristics, such as wetlands and the ordinary high water mark (OHWM) ultimately determine where shoreline jurisdiction is located. If the parcel or project is near the shoreline designation area, then it is recommended you consult with planning staff or your qualified professional.

Layer List

Layers

- Construction Limit Line
- ▾ Geomorphic Class
 - Spit/Barrier/Backshore
 - High Bluff
 - Low Bank
 - Marsh/Lagoon
 - Rocky Shore
- Geomorphic Shore Type
- Potential 0-3% Sloping Bottoms
- ▾ Shoreline Designations 
 - ▭ Priority Aquatic A
 - ▭ Priority Aquatic B
 - ▭ Shoreline Residential Conservancy
 - ▭ Shoreline Residential
 - ▭ Island Conservancy
 - ▭ Natural
 - ▭ Urban
 - ▭ others

6. To determine which land uses and developments are permitted, conditionally permitted, or prohibited, refer to the shoreline designation and Table 4-1 on page 40 in the [Shoreline Master Program](#) (SMP).
7. To determine required shoreline buffer depths, select the Geomorphic Class layer. Use the shoreline designation, geomorphic class, and Table 4-3 on page 64 in the [Shoreline Master Program](#) (SMP) to determine the required total buffer depth.